



DR. WEIGERT
Systematic Hygiene

Always on Hand
to Help with Hygiene –
**in Europe and Around
the World.**



Chemische Fabrik
Dr. Weigert GmbH & Co. KG
Mühlenhagen 85
20539 Hamburg
Tel.: +49-40-7 89 60-0
info@drweigert.de

Dr. Weigert
Handelsgesellschaft m.b.H.
Wienerbergstraße 11/12 a
1100 Wien
Tel.: +43-1-99460 6275
info@drweigert.at

Dr. Weigert (Schweiz) AG
Baarerstrasse 14
6300 Zug
Tel.: +41-41 561 32 90
info@drweigert.ch

Dr. Weigert Nederland BV
Narcisstraat 14
9404 RK Assen
Tel.: +31-592-31 93 93
info@drweigert.nl

Dr. Weigert UK Ltd
Watling Court, Orbital Plaza,
Watling Street, Cannock
WS11 0EL
Tel.: +44-1543 404 633
enquiry@drweigert.com

Dr. Weigert Polska Sp. z o.o.
ul. Wybrzeże Gdynińskie 6A
01-531 Warszawa
Tel.: +48-22-616 02 23/31
office_pl@drweigert.com

Dr. Weigert España
Edificio Cuzco IV
Paseo de la Castellana 141,
Planta 8
28046 Madrid
Tel.: +34-91 572 65 77
info.spain@drweigert.com

Dr. Weigert France SAS
22 avenue des Nations
Immeuble le Raspail
BP 88035 Villepinte
95932 Roissy CDG Cedex
Tel.: +33-1-48 67 90 33
info@drweigert.fr

Dr. Weigert Hungária Kft.
Hunyadi János út 16
1117 Budapest
Tel.: +36-1-237 06 04
Info@drweigert.hu

Dr. Weigert Management System – Certified according to DIN EN ISO 9001/13485/14001

www.drweigert.com



DR. WEIGERT
Systematic Hygiene

Kitchen



neoform K plus
neoform K Spray

Cleaning and Disinfection of Surfaces and
Equipment in the Area of Food Processing

neoform K plus – For Daily Cleaning and Disinfection

neoform K plus

Combined cleaning and disinfection for perfect results at low cost:

- excellent cleaning performance and a high level of material compatibility



200 kg drum
3223 13



10 L canister
3223 30



6x 2 L bottle
3223 42

Reliable and Efficient:

- bactericidal and yeasticidal activity already given at a concentration of 0.5 % and a contact time of only 15 minutes (20 °C)
- suitable for use in cooled areas (10 °C and 4 °C)
- the use of perfumes, colouring agents and aldehydes is intentionally avoided

Application Recommendations:

bactericidal and yeasticidal according to EN 13697

For cleaning and disinfection
(all surfaces – pre-cleaned & dirty)

5 ml/l (0.5 %),
15 min, 20 °C
20 ml/l (2.0 %),
60 min, 10 °C
30 ml/l (3.0 %),
60 min, 4 °C

For disinfection
(pre-cleaned surfaces)

5 ml/l (0.5 %),
15 min, 20 °C
10 ml/l (1.0 %),
5 min, 20 °C

active against enveloped viruses according to RKI1 / DVV2

For cleaning and disinfection
(all surfaces – pre-cleaned & dirty)

10ml/l (1.0 %),
15 min, 20 °C

Our Competence - Your Benefit:

- broad activity spectrum, short contact times
- safe disinfection and an excellent cleaning performance
- high level of material compatibility
- easy to rinse off
- good foaming activity
- free of perfumes, colouring agents and aldehydes



- extensive hygiene safety, quick results
- hygiene and cleanliness in only one step
- universal application with water-proof surfaces and equipment
- hygienic residue-free surfaces
- optimum wetting for maximum activity also on vertical surfaces
- prevention of allergy risks and undesired odour development; pleasant odour

neoform K Spray – Quick Intermediate Disinfection

neoform K Spray

Disinfecting small surfaces and equipment with neoform K Spray achieves safe results in record time:

- ideal for disinfecting working surfaces between two working steps and for areas which are difficult to access



10 L canister
3638 30



12x 0.75 L bottle
3638 47

Rapid and Multi-functional:

- bactericidal and yeasticidal activity after a contact time of only 15 seconds, active against noroviruses after a contact time of 2 minutes
- also suitable for disinfection in cooled areas (10 °C)
- leaves no residues – rinsing is not necessary
- suitable for wiping and spraying
- free of perfumes, colouring agents and aldehydes

Application Recommendations:

bactericidal and yeasticidal according to EN 13697

For disinfection
(pre-cleaned surfaces)

concentrate,
15 sec, 20 °C
concentrate,
15 sec, 10 °C

fungicidal according to EN 13697

For disinfection
(pre-cleaned surfaces)

concentrate,
3 min, 20 °C

active against enveloped viruses according to RKI1 / DVV2

For disinfection
(pre-cleaned surfaces)

concentrate,
15 sec, 20 °C

active against noroviruses (MNV3) according to EN 14476

For disinfection
(pre-cleaned surfaces)

concentrate,
2 min, 20 °C

Our Competence - Your Benefit:

- very short contact time
- active against noroviruses
- dries rapidly without leaving residues
- suitable for wiping and spraying
- free of perfumes, colouring agents and aldehydes



- Hygiene safety without waiting times
- prevention of common norovirus infections
- no product residues, no additional rinsing - therefore time-saving
- easy and multi-purpose application
- prevention of allergy risks and unpleasant odour development