

neodisher® 62

Special cleaning agent in powder form with antifoaming action
for use in baking tray and pot washing machines.



Main fields of application:

Use in washing machines for containers, pans and baking trays as well as utensils in the bakery and meat products industry. Also suitable for dishwashing in single- and multi-tank machines with transport system.

Characteristics:

neodisher 62 is a mildly alkaline detergent in powder form with very good emulsifying power. Removes food residues, especially protein and starch residues and residues of meat, sausage and pastry products. Residues of fresh and baked dough and of prepared food are rapidly swollen, emulsified and decomposed.

Foaming is largely prevented by the foam suppressant in neodisher 62.

Ordinary materials such as stainless steel, aluminium, plastics, ceramic and glass are not attacked by neodisher 62.

neodisher 62 can be used with water of any degree of hardness.

Application and dosage:

In container, pot and baking tray washing machines and equipment dishwashers: 3 - 5 g/l.

In machines without fresh water system, add neodisher 62 to the hot water when starting the wash, at the rate of 150 g neodisher 62 (1 measuring cup) to 50 l tankwater. Add another 75 g (1/2 cup) after every 5 wash loads.

Subsequently the neodisher 62-solution has to be rinsed out completely by sufficient rinsing.

To avoid overloading the cleaning solution, larger food particles must first be removed from containers and pots, possibly by a manual pre-wash with a special low-foam precleaner, e.g. neodisher TV (MB 3310) or neodisher TV flüssig (MB 3311).

Do not mix with other products.

Technical data:

Bulk density: 935 - 975 g/l

pH-range (determined in deionised water, 20 °C) 3 - 5 g/l: 11.8 - 12.2

Titration factor: 0.38 (in accordance with neodisher titration method).

Ingredients:

Ingredients according to Regulation (EC) No 648/2004 on detergents:

5 - 15 % non-ionic surfactants

> 30 % phosphates

Storage information:

Keep container tightly closed. The product is sensitive to moisture.

Hazard and precautionary statements:

For safety information see EC safety data sheets. These are available at www.drweigert.com under the category "Download".

If applied according to the instructions for use the product is safe according to the appropriate guidelines for food processing.

Dispose only when container is empty and closed. For disposal of product residues, refer to the Material Safety Data Sheet.

MB 3210 GB/2-2
10/14



Chemische Fabrik Dr. Weigert GmbH & Co. KG
Mühlenhagen 85, D - 20539 Hamburg

Telefon: (040) 789 60-0
Telefax: (040) 789 60-120

E-Mail: info@drweigert.de
Internet: www.drweigert.de

Die Angaben dieses Merkblattes beruhen auf unseren derzeitigen Kenntnissen und Erfahrungen. Sie befreien den Verwender nicht von eigenen Prüfungen und Versuchen. Eine rechtlich verbindliche Zusicherung bestimmter Eigenschaften kann hieraus nicht abgeleitet werden.

With the above information, which is appropriate to our current knowledge we describe our product regarding possible safety necessities, but we do not involve any quality description or promise certain properties.