



triformin[®] safeDIS



Hand disinfectant

Ready-for-use solution

Fields of application:

- Hygienic hand disinfection in all areas of food production, processing and preparation

Performance spectrum:

- Bactericidal, yeasticidal and virucidal (including norovirus)
- VAH¹-listed
- Listed in the FiBL input list for organic production in Germany

Special properties:

- With skin care and re-moisturising components
- Excellent skin tolerance, confirmed in dermatological reports
- Alcohol-based, free of colouring agents and perfumes

Application and dosage:

For hygienic hand disinfection apply 3 ml triformin safeDIS on the clean and dry skin and allow it to act for 30 sec. Keep your hands moist when disinfecting them with triformin safeDIS and observe the correct rubbing method for disinfecting all parts of your hands.

Hygienic hand disinfection	
bactericidal, yeasticidal and virucidal activity	3 ml – 30 sec

In addition to hygienic hand disinfection with triformin safeDIS we recommend the skin care cream triformin care and the skin protection cream triformin protect.

General instructions on use:

- For professional use only.
- For dosing triformin safeDIS from the 1,000 ml bottle we recommend the triformin dispenser 1.0 resp. from the 500 ml bottle the triformin dispenser 0.5.
- Do not mix with other products.
- *Use disinfectants safely. Always read the label and product information before use.*

Technical data:

pH-value	3.4 (ready-for-use-solution, 20 °C)
Viscosity	1.5 mPa s
Density	0.9 g/cm ³ (20 °C)
Flashpoint	19.5 °C according to Abel-Pensky

Ingredients:

Active substances in 100 g:
64.0 g ethanol
8.0 g propan-1-ol

Storage information:

Keep container tightly closed. Always store at a temperature between -20 °C and +30 °C. Do not expose to direct sunlight.

Usable for 36 months when stored as recommended.

For expiry date refer to the stamp mark on the label behind the hourglass symbol .

In-use shelf life: 6 months.



Hazard and precautionary statements:

For safety information see EC safety data sheets. These are available at www.drweigert.com under the category "Service/Downloads".

If applied according to the instructions for use the product is safe according to the appropriate guidelines for food processing.

Dispose only when container is empty and closed.
For disposal of product residues, refer to the Safety Data Sheet.

MB 3242/3-5

Date of Issue: 01/2025

1 Association of Applied Hygiene (Verbund für Angewandte Hygiene)

With the above information, to our current knowledge we describe our product regarding safety necessities, but we do not involve any quality description or promise certain properties

